



# CAPTURE ONE FOR FUJIFILM

FUJIFILM			
Modelo	Formato compatible	Tethered/Live View	Notas
Fujifilm GFX 100S	RAF	Si/Si	Xtrans a DNG no compatible
Fujifilm X-E4	RAF	No/No	Xtrans a DNG no compatible
Fujifilm GFX 100	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm GFX 50R	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm GFX 50S	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm X-Pro3	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm X-Pro2	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm X-Pro1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-H1	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm X-T4	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm X-T3	RAF	Si/Si*	Xtrans a DNG no compatible
Fujifilm X-T2	RAF	Si/Si*	-
Fujifilm X-T1	RAF	Si/No*	Xtrans a DNG no compatible
Fujifilm X100V	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X100F	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X100T	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X100S	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X100	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-T200	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-T100	RAF	No/No	Xtrans a DNG no compatible

Fujifilm X-S10	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-T30	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-T20	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-T10	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A20	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A10	RAF	No/No	Xtrans a DNG no compatible
Fujifilm XT10	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X10	RAF	No/No	Xtrans a DNG no compatible
Fujifilm XQ2	RAF	No/No	Xtrans a DNG no compatible
Fujifilm XQ1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A7	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A5	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A3	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A2	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-A1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-M1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-S1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-E3	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-E2s	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-E2	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X-E1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm XF10	RAF	No/No	Xtrans a DNG no compatible
Fujifilm XF1	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X70	RAF	No/No	Xtrans a DNG no compatible

Fujifilm X30	RAF	No/No	Xtrans a DNG no compatible
Fujifilm X20	RAF	No/No	Xtrans a DNG no compatible
Fujifilm S5 Pro	RAF	No/No	Xtrans a DNG no compatible
Fujifilm S3 Pro	RAF	No/No	Xtrans a DNG no compatible
Fujifilm S2 Pro	RAF	No/No	Xtrans a DNG no compatible